


DSP

Effector microphone integrated machine

Please read all instructions before use for best performance of this product.
Save these instructions for future reference.


Function introduction



- Computer debugging interface
- Restore factory settings
- Next page
- Previous page
- Next line
- Previous line
- Exit/Save
- Input selection (AUX1/AUX2/BT)
- Input channel display icon (AUX1,AUX2,BT)
- Frequency shift mode display icon (mode 1-3)
- Mode display icon (scene mode 1-16)
- Microphone sound display icon
- A/B microphone connection indicator icon
- Function knob, adjust the total volume of the microphone in normal state, and adjust the function option parameters when entering the menu
- Function knob, adjust the total volume of the microphone normally, and adjust the function option parameters when entering the menu
- Function knob, adjust the total volume of the microphone in normal state, and adjust the function option parameters when entering the menu


1

Audio equipment connection diagram



14


Device attachment



Computer debugging interface

13


Function introduction



- Power input DC port
- Power switch
- Audio mixed output
- Center output
- Subwoofer output
- Front L output
- Front R output
- Front L output
- Aux2 input
- Aux1 input
- Microphone input
- Microphone B antenna
- Microphone A antenna

2


MICROPHONE PARTS & CONTROLS



- Microphone Head:** Includes microphone cover and cartridge.
- LED Display Screen:** Shows channel, battery level, connection range, and frequency.
- Microphone Power Button:** Pressing this button will turn on the microphone. When the microphone is on, holding down the button for 2 to 3 seconds will shut the power off.
- Frequency Adjustment Button:** This button, marked "HI LO", is accessible by unscrewing the microphone base/battery cover. Pressing the button changes the channel/frequency.

3

Display function



11

MICROPHONE PARTS & CONTROLS

- Microphone Head:** Includes microphone cover and cartridge.
- LED Display Screen:** Shows channel, battery level, connection range, and frequency.
- Microphone Power Button:** Pressing this button will turn on the microphone. When the microphone is on, holding down the button for 2 to 3 seconds will shut the power off.
- Frequency Adjustment Button:** This button, marked "HI LO", is accessible by unscrewing the microphone base/battery cover. Pressing the button changes the channel/frequency.

4

MICROPHONE PARTS & CONTROLS

Microphone Transmitter LED Display



- Battery Level Display:** This icon displays the remaining battery power. When the battery level is low, the icon will flash, indicating that it needs replacing.
- Channel Display:** This alphanumeric display shows the current channel.
- Frequency Display in MHz:** This numeric display shows the current frequency.

5

Display function

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	-0.3 to 3.9
Analog Input Voltage	/	-25 to 85
Operating Temperature Range	/	°C
Storage Temperature Range	/	-65 to 150

over operating free-air temperature range (unless otherwise noted)

	VALUE	UNIT
Supply Voltage	AVDD, CPVDD, DVDD	-0.3 to 3.9
Digital Input Voltage	/	